

INGRAM ENTERPRISES INC

FUEL INJECTION SPECIALISTS

15613 Peterson Road, Bldg C, Burlington, WA 98233

Injection pump shipping instructions

1. Scrape and clean the exterior of the pump for shipping.
2. Remove the rear inspection plate (4 screws).
3. Stand the pump upright for one day to drain the oil. Replace the (4) screws finger tight.
4. Place the pump in a sealed plastic bag.
5. Pack the injectors in a small bag.
6. Pack the Actuator between two sections of cardboard for protection. Do not bend the small tube.
NOTE: FOR MONTREAL 8C PUMPS, REMOVE THE LOWER BASE. DO NOT SEND AS THEY ARE EASILY DAMAGED IN SHIPPING.
7. A strong but compact cardboard box works very well. Use Bubble wrap or wadded up newspaper all around the corners of the pump. **Please do not use foam pellets of any kind:** pack as tight as possible to protect from rough handling and impact.
8. **It is important to include previous emails along with your name, mailing address, and contact info inside the box.**
9. Wrap and compress the box with generous layers of stretch tape. If the contents rattle or shift, you must open the box and re-pack as needed.

STOP: DID YOU INCLUDE A NOTE IN THE BOX WITH YOUR NAME, ADDRESS, PHONE NUMBER AND EMAIL ADDRESS?